


HP-120DXT

SPARE PARTS DIAGRAM



- | | | |
|----|------------|-------------------------------|
| 1. | SP-HP14 | Bolt & Nut |
| 2. | SP-120DX15 | Spring |
| 3. | SP-HP16 | Steel Hook |
| 4. | | Upper Holding Device |
| 5. | | Lower Holding Device |
| 6. | | Bolt for Upper Holding Device |
| 7. | | Bolt for Lower Holding Device |

*All highlighted items are available from inventory.
All others are available by Special Order.*